Jameco Part number 136397

EPIC 8/18 Pin ZIF Adapter

Copyright C 1997 microEngineering Labs, Inc.



USE:

Plug the 8/18 Pin ZIF Adapter into the 10 pin header near the bottom of the EPIC Programmer. Make sure the EPIC Programmer is powered up and the EPIC software is running before inserting a PIC into the 8/18 Pin ZIF Adapter.

To insert a PIC into the adapter, lift the lever on the socket. Position the 8 or 18 pin PIC with pin one all the way toward the lever end of the socket and push down the lever to lock the PIC in place.